


Country Hearts End Table Assembly Instructions

Models: WF4102CVD


Tools needed for assembly:

Drill.
Pliers and 1/4" socket set.
Hammer

- Step 1 Bolt the 4 legs to the top with (4) 3" bolts.
Use a washer under the head, and the nut both. Finger tighten for now.
- Step 2 Bolt the (2) #1 braces to the inside of the legs with the rest of the bolts, nuts & washers.
Tighten all 8 bolts firmly.
- Step 3 Hold the #2 brace in place between the (2) #1 braces and tap the (4) screws through the holes provided, with a hammer, then turn them the rest of the way in with a Phillips screwdriver.



Side View



Front View

Note: Due to product variations, the parts list may be different than what you actually receive with your product.

Parts List For End Table

1 – Table Top
4 – Legs
2 – #1 Braces
1 – #2 Brace

Hardware

8 – 3" Bolts
16 – Washers
8 – 1/4" Nuts
4 – 3" Screws