


Assembly Instructions for 4', 5', 6', 8', and 10' Red Cedar Cross Legged Picnic Tables w/ Benches

Step 1 Lay out and identify all parts.

Step 2 Take the table top and lay it upside down on a flat clean surface (we recommend using the box that the top was shipped in for a flat and clean surface).

Take the table legs and attach them to the top of the table. Be sure the braces face the inside of the table top



Step 3 Line up the pre-drilled holes and tap a hex bolt through them. If the holes aren't lining up, loosen the two nuts on the leg to allow for play. Once aligned, put on a washer and nut and tighten.

NOTE: *10' size includes an additional Leg Assembly for the center of the table, this is attached the same way as the other legs.*

Step 4 Next, take a lag bolt and twist it into the brace and into the underside of the table top and into the leg. Do the same with the other leg.

Step 5 Set your table upright and lay the benches on top of the table upside down. Follow the same procedure as in Steps 1-4 with the smaller legs for assembling the benches.

NOTE: *Braces for the 4 foot table will have different angles in order to accommodate an umbrella pole.*

NOTE: *Due to product variations, the parts list and hardware lists may be differ from what you actually receive with your product.*

Parts List

Table Top (1)
Bench Top (2-4)
Table Leg Assembly (2) (3 for 10' table)
Bench Leg Assembly (4-8)
Braces (6-11)

Hardware

1/4" X 2-1/2" Lag Bolts (12-14)
1/4" x 3" Hex Bolts (12-14)
1/4" Hex Nuts (12-14)
Small Washers (12-14)
1/4" X 1" Fender Washers (24-28)

Required Tools

1/4" Socket Wrench
Hammer
#2 Square Bit (included)

Fully Assembled Table and Benches



5 Foot Table Shown Above