


Instructions for 4', 5', 6', 8', 10' Red Cedar Picnic Table



Step 1:


Lay the table top upside down on a clean flat surface. We recommend using the box the table was shipped in. Place each leg assembly on the inner edge of the 2x2 top support and fasten each side with two 3" Hex bolts (placing a washer at each end of the bolt). Please be sure the leg assembly is square with the bench top.

Tools Required for Assembly

-7/16" Socket or Adjustable Wrench

-#2 Squarehead Drill Bit (included)

-Hammer for tapping bolts & screws



Step 2:

Use the 2 1/2" lag screws to attach the angled braces, making sure to place a small washer at the top of each screw. We have found that it is sometimes easier to start each screw or bolt by tapping it once with a hammer.

Step 3:

Turn the table upright. Tighten the screws and/or bolts if necessary.

Parts List

Table Pieces:

- 1 Table Top
- 2 Leg Assemblies
- 2 Braces

Hardware

- 4 3" x 1/4" Hex Bolts
- 4 2 1/2" x 1/4" Hex Lag Screws
- 4 1/4" Hex Nuts
- 8 1 1/4" Fender Washers
- 4 1/4" Small Washers
(for Lag Screws)

- Hex Bolt 
- Hex Lag Screw 
- Large Washer 
- Small Washer 
- Nut 
- Predrilled Hole 