

# Assembly Instructions for Cedar End Tables & Coffee Tables

Tools needed for assembly:

Drill.

Pliers and 1/4" socket set.

Hammer


Step 1 Bolt the 4 legs to the top with (4) 3" bolts.

Use a washer under the head, and the nut both. Finger tighten for now.


Step 2 Bolt the (2) #1 braces to the inside of the legs with the rest of the bolts, nuts & washers.

Tighten all 8 bolts firmly.

Step 3 Hold the #2 brace in place between the (2) #1 braces and tap the (4) screws through the holes provided, with a hammer, then turn them the rest of the way in with a Phillips screwdriver.



Side View



Front View

**Note:** Due to product variations, the parts list may be different than what you actually receive with your product.

## Parts List For End Table and Coffee Table

1 – Table Top

4 – Legs

2 – #1 Braces

1 – #2 Brace

1 – #2 Square Bit

## Hardware

8 – 3" Bolts

16 – Washers

8 – 1/4" Nuts

4 – 3" Screws