



Instructions for 4', 5', 6', 8', 10' Red Cedar Backless Benches




Bench Top - Bottom View



Leg Assembly Side View

Step 1

Lay the bench top upside down on a clean flat surface. Place each leg assembly on the inner edge of the 2x2 top support and fasten with a 3" hex bolt (placing a washer at each end of the bolt). Please be sure the leg assembly is square with the bench top.



Step 2

Use the 2 1/2" lag screws to attach the angled braces, making sure to place a small washer at the top of each screw.

Step 3

Turn the bench upright. Tighten the screws and/or bolts if necessary.

Tools Required for Assembly

- 7/16" Socket or Adjustable Wrench
- #2 Squarehead Drill Bit (included)
- Hammer for tapping bolts and screws

Parts List







Bench Pieces

- 1 Bench Top
- 2 Leg Assemblies
- 2 Braces

Hardware

- 2 3" x 1/4" Hex Bolts
- 4 2 1/2" x 1/4" Hex Lag Screws
- 2 1/4" Hex Nuts
- 4 1 1/4" Fender Washers
- 4 1/4" Small Washers (for Lag Screws)

KEY

- Hex Bolt 
- Hex Lag Screw 
- Nut 
- Large Washer 
- Small Washer 
- Predrilled Hole 

*We have found that it is sometimes easier to start each screw or bolt by tapping it once with a hammer.